

**SECTION 9  
SUPPLEMENTS**

**OPTIONAL EQUIPMENT SUPPLEMENTS**

Information contained in the following supplements applies only when the related equipment is installed.

**CONTENTS**

	<b>Page</b>
Peak Beam Searchlight . . . . .	9-4.1
Fixed Floats . . . . .	9-5.1
Heated Pitot . . . . .	9-6.1
Police Version . . . . .	9-7.1
ENG Version . . . . .	9-8.1
Garmin GPSMAP 225 . . . . .	9-9.1
Pop-Out Floats . . . . .	9-10.1
ADS-B Equipment . . . . .	9-12.1
Autopilot . . . . .	9-13.1

**NON-U.S. SUPPLEMENTS**

The following supplements contain additional information required by certain countries:

- Canadian Supplement
- CIS Supplement
- EASA Supplement
- Ukrainian Supplement

INTENTIONALLY BLANK

FAA APPROVED  
R44 PILOT'S OPERATING HANDBOOK

SUPPLEMENT 4  
PEAK BEAM SEARCHLIGHT

This supplement must be included in the FAA-Approved Robinson R44 Pilot's Operating Handbook when the Peak Beam Searchlight is installed.

The information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic R44 Pilot's Operating Handbook.

APPROVED BY:



Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE:

12-13-95

LOG OF REVISIONS

Page No.	Date	Page No.	Date
9-4.1	11 Jul 97	9-4.3	11 Jul 97
9-4.2	11 Jul 97	9-4.4	11 Jul 97

REVISIONS

APPROVED BY:



Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE:

7-11-97

**SECTION 1: GENERAL**      No change.

**SECTION 2: LIMITATIONS**

**FLIGHT AND MANEUVER LIMITATIONS**

If removable controls are installed with searchlight, the A755-14 extended LH pedal must be installed in place of the A755-3 pedal.

**SECTION 3: EMERGENCY PROCEDURES**      No change.

**SECTION 4: NORMAL PROCEDURES**

**DAILY OR PREFLIGHT CHECKS**

Add to item 11, Fuselage Left Side:

Searchlight . . . . . Secure

**SECTION 5: PERFORMANCE**

**NOISE CHARACTERISTICS**

These modifications have been determined to not be an "acoustical change."

**SECTION 6: WEIGHT AND BALANCE**      No change.

## SECTION 7: SYSTEMS DESCRIPTION

### SEARCHLIGHT INSTALLATION

The searchlight installation consists of two lamps suspended below the cabin chin on a post which extends through the left hand side of the chin and cabin floor. The searchlight is controlled by means of a grip and switches mounted on the post. Power is supplied to the searchlight through its own 20 amp circuit breaker and power relay. The searchlight will operate only when the landing lights are off. A friction control for horizontal beam movement is located on the post just above the floor, and later models include a friction control for vertical beam movement located at the top of the post. An extended left foot pedal is provided which allows the co-pilot's foot to clear the searchlight post.

The lights are manufactured by Peak Beam Systems and use xenon arc lamps controlled by four momentary toggle switches on the grip. These switches control on-off, strobe (rapidly flashing) mode, and beam spread from 1° spot to 40° flood.

### CAUTION

When operating the searchlight with left seat cyclic grip installed, caution should be exercised to prevent interference with the cyclic control.

## **SECTION 8: HANDLING AND MAINTENANCE**

### **SEARCHLIGHT INSTALLATION**

To remove the searchlight from the helicopter, use the following procedure:

1. Loosen but do not remove two 1/4 in. diameter bolts (or the cam-action lever if so equipped) in clamp on bottom end of post.
2. Remove clevis pin connecting lower end of tube through center of post to arms between lamps.
3. Disconnect wires from lamps at connectors and wire ties on lamp housings.
4. Pull ring on spring-loaded pin in post clamp and slide clamp with lamps off post.
5. Remove four screws (or lift and turn two spring loaded fasteners if so equipped) holding post flange to cabin floor. Pull post up a few inches and disconnect wires at post connector. Before releasing, O-ring around connector must be moved clear of retaining hooks. Pull post up and out of floor.
6. Cover connector under floor with tape and install provided sheet metal cover over hole in floor.

Installation is the reverse except:

1. Be sure to position O-ring under retaining hooks on post wire connector.
2. Letters "FWD" on post flange must face forward.
3. Be sure spring loaded pin in post clamp pops into place. Torque 1/4 in. diameter bolts to 90 in.-lb (or secure cam-action lever if so equipped).
4. Check for freedom of movement through complete travel.

FAA APPROVED  
R44 PILOT'S OPERATING HANDBOOK

FIXED FLOATS SUPPLEMENT

This supplement must be included in the FAA-approved Pilot's Operating Handbook when fixed-float landing gear is installed.

Information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic Pilot's Operating Handbook.

APPROVED BY: Donald C. Anthony  
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: 7-17-96

LOG OF REVISIONS

Page No.	Date	Page No.	Date
9-5.1	20 Apr 07	9-5.8	20 Apr 07
9-5.2	20 Apr 07	9-5.9	20 Apr 07
9-5.3	20 Apr 07	9-5.10	20 Apr 07
9-5.4	20 Apr 07	9-5.11	20 Apr 07
9-5.5	20 Apr 07	9-5.12	20 Apr 07
9-5.6	20 Apr 07	9-5.13	20 Apr 07
9-5.7	20 Apr 07		

REVISIONS APPROVED BY: Hien Tong, Acting  
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: 4/20/07

**SECTION 1: GENERAL**

**INTRODUCTION**

This supplement contains the changes and additional data applicable when fixed-float landing gear is installed.

The fixed-float landing gear installation includes inflated floats, additional airframe sealing and corrosion protection, additional forward position lights in the mast fairing, and longer landing gear struts. An additional stabilizer is installed at the base of the lower vertical stabilizer for controllability. Standard landing gear may be installed in place of the float landing gear per Maintenance Manual instructions.

Float landing gear is intended for safety during flights over water. Intentional water landings for other than training purposes are not recommended.

Note: The float landing gear is approved for amphibious operation but is not certified for ditching. Some countries may prohibit certain over-water operations.

**SECTION 2: LIMITATIONS**

**AIRSPED LIMITATIONS**

**NEVER EXCEED AIRSPEED ( $V_{ne}$ ) WITH FLOATS**

Up to 3000 feet density altitude:

2200 lb TOGW & below	120 KIAS
Over 2200 lb TOGW	110 KIAS
Autorotation	100 KIAS

Above 3000 feet density altitude: See placard on page 9-5.3.



**SECTION 2: LIMITATIONS (cont'd)**

**PLACARDS**

In clear view and readable by the pilot in flight:

**NEVER EXCEED SPEED - KIAS  
WITH FLOATS**

2200 LB TOGW & BELOW							
PRESS	OAT - °C						
ALT - FT	-20	-10	0	10	20	30	40
SL							
2000	120					117	113
4000				116	112	108	104
6000			116	112	107	103	98
8000	112	107	102	97	91	86	81
10000	102	96	91	85	80	75	
12000	91	85	79				
14000	79	NO FLIGHT					
OVER 2200 LB TOGW, SUBTRACT 10 KIAS FOR AUTOROTATION, SUBTRACT 20 KIAS							

**NEVER EXCEED SPEED - KIAS  
WITHOUT FLOATS**

2200 LB TOGW & BELOW							
PRESS	OAT - °C						
ALT - FT	-20	-10	0	10	20	30	40
SL							
2000	130					127	123
4000				126	122	118	114
6000			126	122	117	113	108
8000	122	117	112	107	101	96	91
10000	112	106	101	95	90	85	
12000	101	95	89				
14000	89	NO FLIGHT					
OVER 2200 LB TOGW, SUBTRACT 10 KIAS FOR AUTOROTATION, SUBTRACT 30 KIAS							

Located on floats:

SEE PILOT'S HANDBOOK FOR  
PROPER INFLATION PRESSURE

SECTION 2: LIMITATIONS (cont'd)


FLOAT PRESSURE LIMITS

Minimum Float Pressure: 1.5 psig (psi gage)

Maximum Float Pressure: 5 psig

A decrease in altitude or temperature reduces float pressure. If decrease in altitude or temperature is anticipated, inflate floats per chart below to ensure 1.5 psig minimum at landing. Pressure relief valves will limit pressure for an increase in altitude or temperature.

REQUIRED FLOAT PRESSURE VS.  
CHANGE IN ALTITUDE AND TEMPERATURE



**CAUTION**

Failure to maintain adequate pressure can result in loss of buoyancy or in-flight instability.

EXAMPLE:

	Pressure	
Conditions at destination:	<u>Altitude</u>	<u>Temp</u>
Initial conditions:	1000 ft	15°C
	5500 ft	5°C
Subtract to obtain change		
in altitude and temp:	<u>-4500 ft</u>	<u>+10°C</u>

Using graph, locate -4500 ft line, read across to +10°C line, then down for minimum initial float pressure required, approximately 3.2 psig.

### SECTION 3: EMERGENCY PROCEDURES

#### GENERAL

Without floats, emergency procedures in the basic manual apply. With floats, the following procedures are applicable.

#### POWER FAILURE ABOVE 500 FEET AGL

Autorotation to Land: Same as in basic manual.

Autorotation to Water:

1. Lower collective immediately to maintain RPM.
2. Establish steady glide at approximately 70 KIAS.
3. If altitude permits, maneuver into wind.
4. At about 40 feet AGL, begin cyclic flare.
5. At about 8 feet AGL, apply forward cyclic and raise collective just before touchdown. Touch down in slight nose high attitude with nose straight ahead.
6. Maintain cyclic in touchdown position and do not lower collective full down until forward motion has stopped.

#### CAUTION

Lowering collective or applying forward cyclic while helicopter is moving forward on water can cause floats to submerge and helicopter to nose over.

**SECTION 3: EMERGENCY PROCEDURES (cont'd)**

**POWER FAILURE BETWEEN 8 FEET AND 500 FEET AGL**

Autorotation to Land: Same as in basic manual.

Autorotation to Water:

1. Lower collective immediately to maintain RPM.
2. If altitude permits, maneuver into wind.
3. Maintain airspeed until water is approached, then begin cyclic flare.
4. At about 8 feet AGL, apply forward cyclic and raise collective just before touchdown. Touch down in slight nose high attitude with nose straight ahead.
5. Maintain cyclic in touchdown position and do not lower collective full down until forward motion has stopped.

**CAUTION**

Lowering collective or applying forward cyclic while helicopter is moving forward on water can cause floats to submerge and helicopter to nose over.

**MAXIMUM GLIDE DISTANCE CONFIGURATION**

Same as without floats, except airspeed approximately 80 KIAS.

**DITCHING**

Not applicable with floats.

**SECTION 4: NORMAL PROCEDURES**

**DAILY OR PREFLIGHT CHECKS**

15. Inflatable Floats

Float Pressure . . . . . Check (See Section 2)

Float Condition . . . . . Check

***CAUTION***

Helicopters equipped with inflated floats have an adverse roll characteristic. When sideslipping nose left or right, helicopter will tend to roll in opposite direction and could cause loss of control. To avoid adverse roll, keep helicopter trimmed with zero sideslip. Exercise extreme caution when performing simulated power failures.

***CAUTION***

Avoid night flight over water beyond autorotation distance to land. Height above water may be difficult to judge during a water landing.

**SECTION 4: NORMAL PROCEDURES (cont'd)**

**OPERATION ON WATER**

Since the helicopter sits very low on water, it is likely that water will leak into the cabin. Water landings should be limited to emergencies and training. For training, seal the removable belly panels and landing gear cross tube cover using aluminum foil tape or duct tape. Avoid salt water if possible.

Maximum recommended water taxi speed is 5 knots. Some application of collective is required.

**CAUTION**

To avoid contacting rotor teeter stops, do not apply full cyclic control during water taxi.

**CAUTION**

If starting or stopping rotor on water, ensure area is clear as helicopter can rotate one or more complete turns while tail rotor RPM is low.

**NOTE**

Safe operation on water has been demonstrated in waves up to 12 inches (trough to crest).

**SECTION 4: NORMAL PROCEDURES (cont'd)**

**PRACTICE AUTOROTATION - WITH GROUND CONTACT**

Same as in basic manual. Autorotations should only be performed to a smooth, hard surface to avoid damage to floats.


**PRACTICE AUTOROTATION - WITH WATER CONTACT**

Same as practice autorotation with ground contact in basic manual except touch down in slight nose high attitude with nose straight ahead. Maintain cyclic in touchdown position and do not lower collective full down until forward motion has stopped.

**CAUTION**

Lowering collective or applying forward cyclic while helicopter is moving forward on water can cause floats to submerge and helicopter to nose over.

**SECTION 5: PERFORMANCE**



**AIRSPEED CALIBRATION CURVE**

**R44 WITH FIXED FLOAT LANDING GEAR**



**SECTION 6: WEIGHT AND BALANCE**

***CAUTION***

When changing between float and non-float configurations, weight and balance must be revised and autorotation RPM readjusted per R44 Maintenance Manual.

**WEIGHT AND BALANCE RECORD**

Basic empty weight and CG in float and non-float configurations is included in the Weight and Balance Data provided with the helicopter. Modifications are to be recorded in Section 6 of the basic manual.

**SECTION 7: SYSTEMS DESCRIPTION**

No change.

## **SECTION 8: HANDLING AND MAINTENANCE**

### **GROUND HANDLING**

With floats installed, special ground handling wheels are required. Refer to R44 Maintenance Manual for wheel installation and removal procedures.

### **FLOAT TUBES**

To promote long float tube life:

1. Do not inflate floats to higher pressure than required by limitations section. Do not arbitrarily inflate floats to relief valve pressure.
2. Reduce pressure in floats if solar heating is causing excessive pressure buildup.
3. Do not allow floats to sit uninflated. Maintain some pressure to keep shape when not in use.

### **CAUTION**

When inflating chambers individually (without a manifold), increase pressure in each chamber in increments no greater than 0.5 psig.

**SECTION 10: SAFETY TIPS**

Flight characteristics and handling qualities with inflated floats are more critical than with conventional landing gear. Helicopters with floats installed have an adverse roll characteristic. When sideslipping nose right or left, the helicopter will tend to roll in the opposite direction out of the turn. This could be extremely dangerous if a pilot failed to apply right pedal or put in the wrong pedal during a simulated power failure. Also, aerodynamic lift produced by floats makes both RPM and pitch control more difficult during autorotation entries. Helicopters with floats installed are also more gust sensitive and difficult to fly in turbulence.

For these reasons, it is strongly recommended that floats be removed and standard gear installed for primary flight instruction. With floats installed, pilots must keep the helicopter trimmed with zero sideslip and exercise extreme caution when performing simulated power failures.

INTENTIONALLY BLANK

FAA APPROVED  
R44 PILOT'S OPERATING HANDBOOK

HEATED PITOT SUPPLEMENT

This supplement must be included in the FAA-approved Pilot's Operating Handbook when the heated pitot is installed.

Information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic Pilot's Operating Handbook.

APPROVED BY: Sam Greber, Acting  
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: Sept 27, 1996

LOG OF REVISIONS

Page No.	Date	Page No.	Date
9-6.1	20 Apr 07	9-6.3	20 Apr 07
9-6.2	20 Apr 07	9-6.4	20 Apr 07

REVISIONS  
APPROVED BY: Hieu Tong, Acting  
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: 4/20/2007

**SECTION 1: GENERAL**

**INTRODUCTION**

This supplement contains the changes and additional data applicable when the heated pitot is installed.

**SECTIONS 2 and 3**      No change.

**SECTION 4: NORMAL PROCEDURES**

**USE OF PITOT HEAT**

When conditions conducive to pitot ice exist, switch pitot heat on until landing or until no longer in potential icing conditions.


***NOTE***

The R44 is not certified for flight into known or suspected icing conditions.

***NOTE***

Continued use of pitot heat following an engine or alternator failure will significantly increase battery drain.

**SECTION 5: PERFORMANCE**



**AIRSPEED CALIBRATION CURVE**

**HEATED PITOT INSTALLATION  
VALID WITH PITOT HEAT ON OR OFF**

**SECTION 6: WEIGHT AND BALANCE**          No change.

**SECTION 7: SYSTEMS DESCRIPTION**

**HEATED PITOT INSTALLATION**

The heated pitot tube is installed in the mast fairing, replacing the standard pitot tube. Pitot heat is controlled by a toggle switch located to the right of the cyclic. Power is supplied to the heated pitot through its own 10-amp circuit breaker.

**SECTION 8: HANDLING AND MAINTENANCE**

***CAUTION***

Pitot tube becomes extremely hot with pitot heat switched on. Touching pitot tube after it has been on for more than 30 seconds can result in severe burns.




FAA APPROVED  
R44 PILOT'S OPERATING HANDBOOK

SUPPLEMENT 7  
POLICE VERSION

This supplement must be included in the FAA-Approved Robinson R44 Pilot's Operating Handbook when the helicopter is configured with optional police equipment.

The information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic R44 Pilot's Operating Handbook.

APPROVED BY:

  
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE:


7-11-97

LOG OF REVISIONS

Page No.	Date	Page No.	Date
9-7.1	26 Aug 02	9-7.5	30 Nov 98
9-7.2	14 Sep 99	9-7.6	26 Aug 02
9-7.3	14 Sep 99	9-7.7	26 Aug 02
9-7.4	30 Nov 98	9-7.8	26 Aug 02

REVISIONS

APPROVED BY:

  
Acting Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE:

August 26, 2002

**SECTION 1: GENERAL**

**INTRODUCTION**

This supplement contains the changes and additional data applicable when the R44 helicopter is equipped with Police Version options.

The Police Version is equipped with a 28-volt electrical system. Additional equipment may include a nose-mounted gyro-stabilized infrared camera with flat-screen LCD monitor, a belly-mounted searchlight, FM transceivers, a video tape recorder, a PA/siren, Lojack equipment, a microwave transmitter, and forward cabin doors with bubble windows. A modified left-side cyclic control allows flight from the left seat with the LCD monitor installed. Extended landing gear provides additional ground clearance for the searchlight. The battery is relocated to the tailcone to balance the weight of the infrared camera.

**SECTION 2: LIMITATIONS**

**PLACARDS**

Located on cover replacing right rear seat:

**DO NOT OCCUPY**

Located in right rear baggage compartment:

**NO STOWAGE**

**SECTION 3: EMERGENCY PROCEDURES**

**POWER FAILURE ABOVE 500 FEET AGL**

If time permits, retract omni antenna.

**SECTION 4: NORMAL PROCEDURES**

**DAILY OR PREFLIGHT CHECKS**

Add to item 4, Aft Cowl Door - Right Side:  
Battery Relay . . . . . Secure

Add to item 8, Tailcone:  
Battery . . . . . Secure

Delete from item 9, Cowl Door - Left Side:  
Battery and Relay . . . . . Secure

Add to item 11, Fuselage Left Side:  
Siren . . . . . Secure

Add to item 12, Nose Section:  
Camera and Fairing . . . . . Secure

Add to item 13, Fuselage Right Side:  
Searchlight . . . . . Secure  
Omni Antenna . . . . . Secure

**NOTE**

Stow searchlight horizontally when not in use to minimize chance of damage during a hard landing.

**APPROACH AND LANDING**

Retract omni antenna.

**SECTION 5: PERFORMANCE**      No change.

**SECTION 6: WEIGHT AND BALANCE**

**CAUTION**

Removal of nose-mounted camera causes a large shift in CG of empty helicopter. Calculate weight and balance prior to flight with camera removed to assure aft CG limit is not exceeded.

## **SECTION 7: SYSTEMS DESCRIPTION**

The following optional equipment may be installed:

### **AIRFRAME**

The R44 is a three-place helicopter when police equipment is installed.

Forward cabin doors with bubble windows to enhance downward visibility replace the standard doors.

### **FLIGHT CONTROLS**

The cyclic control has been modified to prevent interference with the LCD monitor. The left-side removable grip has been replaced with a grip on the center post.

### **ELECTRICAL SYSTEM**

A 28-volt electrical system replaces the standard 14-volt system. The battery has been relocated to a battery box beneath the tailcone to balance the weight of the nose-mounted camera.

An additional circuit breaker panel on the ledge just forward of the pilot's seat contains all circuit breakers for police equipment. The outboard section of the aft row of circuit breakers is a 14-volt bus. A 28- to 14-volt converter located in the compartment under the left rear seat powers the 14-volt bus. The police equipment master switch on the left side of the panel controls power to all police equipment.

Wiring for police equipment is in a separate harness on the right-hand keel panel outside of the control tunnel.

## **SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

### **INTERCOM SYSTEM**

The intercom system is controlled via the audio control panel in the avionics stack. The intercom and transmit switches for the left front seat have been relocated to the floor near the observer's right heel.

### **SEATS, BELTS, AND BAGGAGE**

The right rear seat has been replaced with a cover and cannot be occupied. Baggage is not permitted in the right rear baggage compartment due to electronic equipment and wiring in that compartment.

### **EXTENDED LANDING GEAR**

Extended landing gear struts provide additional ground clearance for the searchlight.

### **INFRARED CAMERA SYSTEM**

The infrared camera system consists of a gyro-stabilized, gimbal-mounted infrared/video camera in the chin, and a power junction box in the compartment beneath the right rear seat. A fairing between the camera ball and chin minimizes the aerodynamic effects of the camera. The camera is operated by the observer in the left front seat via a handheld controller.

A flat screen LCD monitor is located in front of the left front seat to display camera images. The monitor is equipped with a visor to minimize glare from the sun during daylight operation and shield the pilot from the monitor at night. The monitor mount is hinged to retract forward and down, out of the observer's way, when not in use.

**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**VIDEO TAPE RECORDER**

The video tape recorder (VTR) is mounted either on the control tunnel cover between the rear seats or on the monitor support structure and is used to record camera images. The VTR is operated from the left front seat. A remote control mounted on the left side of the monitor visor is provided with the rear-seat VTR.

For the forward-mounted VTR, a toggle switch determines video signal routing. In the REC position, camera images can be recorded by the VTR. In the PLAY position, images being played back on the VTR can be viewed on the monitor.

**SEARCHLIGHT INSTALLATION**

The searchlight is installed on a motorized gimbal under the belly. The searchlight power junction box is located in the compartment beneath the right rear seat. The searchlight is steerable in azimuth and elevation and is operated from the left front seat via a remote controller. An optional slaving system allows the searchlight to be slaved to follow the camera. The searchlight should be stowed horizontally when not in use to minimize chance of damage during a hard landing.

**CAUTION**

The searchlight is very bright and can disorient other pilots or ground personnel at long distances.

**CAUTION**

The searchlight beam is very hot. Exposure to the beam at close range for more than a few seconds can result in burns.

**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**PA/SIREN SYSTEM**

A 100-watt speaker is located on the aft left landing gear strut. The PA system control panel is located on the instrument panel and allows the pilot or observer to select PA, radio, yelp, or siren for broadcast through the speaker.

**FM TRANSCEIVERS**

Four brands of FM transceiver are available on the Police Version: NAT, BK Radio, Motorola, and Technisonic.

NAT and Motorola FM transceivers are mounted in the compartment beneath the right rear seat. A control head located beneath the monitor is used to control tuning and individual radio functions.

BK Radio and Technisonic dual-band FM transceivers are mounted beneath the monitor and incorporate controls on their faceplates.

The FM transceivers are selectable from the audio control panel in the avionics stack.

**INTERIOR LIGHT**

An additional observer-side interior light is operated via a momentary foot switch on the left-hand forward floor. Power is supplied to the interior light via the "GAGES" breaker in the left hand circuit breaker panel and is not disconnected by the police equipment master switch.

**LOJACK**

The Lojack installation consists of a receiver in the compartment beneath the right rear seat, a display and control unit on the right side of the instrument console, and four belly-mounted stub antennas. Lojack is used to track stolen vehicles equipped with Lojack transmitters.

**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**MICROWAVE SYSTEM**

The microwave transmitting system consists of the microwave transmitter beneath the right rear seat, a retractable omnidirectional microwave antenna on the right skid tube, and an optional belly-mounted downlook antenna. If both antennas are installed, a switch forward of the right rear equipment compartment selects which antenna is active. The transmitter is operated via a controller in the rear-center console. The skid-mounted antenna is stowed parallel to the skid tube and rotated down to the vertical position for transmitting. It is actuated by an electric motor with the control switch located on the rear-center console. The antenna is designed to break away without damaging the helicopter if inadvertently left extended during landing. However, damage to the antenna or actuation mechanism may occur.

**CAUTION**

Do not kick or step on antenna. Ensure antenna is retracted before landing.

**SECTION 8: HANDLING AND MAINTENANCE**

**BATTERY SERVICE**

The battery is located in a battery box beneath the tailcone. It is sealed and does not require fluid level checks.

**JUMP STARTING ENGINE**

Jump starting is not recommended due to limited access to battery and relay, and is not possible from a normal auto battery due to the 28-volt electrical system.

For battery charging, access to battery relay terminal A1 (labeled + 24V) and a grounded tab (labeled -) is provided inside the aft cowl door.



FAA APPROVED  
R44 PILOT'S OPERATING HANDBOOK

SUPPLEMENT 8  
E.N.G. VERSION

This supplement must be included in the FAA-Approved Robinson R44 Pilot's Operating Handbook when the helicopter is configured with optional Electronic News Gathering (ENG) equipment.

The information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic R44 Pilot's Operating Handbook.

APPROVED BY: *Donald Armstrong*  
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: *Nov 4, 1997*

LOG OF REVISIONS

Page No.	Date	Page No.	Date
9-8.1	12 Nov 99	9-8.7	8 Apr 98
9-8.2	8 Apr 98	9-8.8	1 Jul 98
9-8.3	8 Apr 98	9-8.9	8 Apr 98
9-8.4	4 Nov 97	9-8.10	1 Jul 98
9-8.5	2 Feb 98	9-8.11	19 Aug 99
9-8.6	8 Apr 98	9-8.12	12 Nov 99

REVISIONS  
APPROVED BY: *[Signature]*  
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: *11/12/99*

## **SECTION 1: GENERAL**

### **INTRODUCTION**

This supplement contains the changes and additional data applicable when the R44 helicopter is equipped with Electronic News Gathering (ENG) options.

The ENG version is equipped with a 28-volt electrical system, a nose-mounted, gyro-stabilized video camera, audio and video cabling to interconnect ENG components, and a rear-center console to house audio and video controls. Additional equipment includes front seat and rear seat flat screen LCD monitors, FM transceivers, a video tape recorder, one to three micro cameras, microwave equipment, and additional interior lighting. The battery is relocated to the tailcone to balance the weight of the nose camera.

## **SECTION 2: LIMITATIONS**

### **WEIGHT LIMITS**

Maximum in left front or right rear seat	250 lb (113 kg)
---	-----------------

### **PLACARDS**

Located in compartments under left front and right rear seats:

**NO STOWAGE**

Located on laptop camera controller, on video titler keyboard, and on handheld microwave keypad:

**STOW DURING TAXI,  
TAKEOFF, AND LANDING**

**SECTION 3: EMERGENCY PROCEDURES**

**POWER FAILURE ABOVE 500 FEET AGL**

If time permits, stow laptop controller, video titler keyboard, and handheld microwave keypad, and retract omni antenna.

**SECTION 4: NORMAL PROCEDURES**

**DAILY OR PREFLIGHT CHECKS**

Add to item 4, Aft Cowl Door - Right Side:  
Battery Relay . . . . . Secure

Add to item 8, Tailcone:  
Battery . . . . . Secure

Delete from item 9, Cowl Door - Left Side:  
Battery and Relay . . . . . Secure

Add to item 12, Nose Section:  
Camera and Fairing . . . . . Secure

Add to item 13, Fuselage Right Side:  
Antenna . . . . . Secure

**CAUTION**

Calculate weight and balance to assure limits are not exceeded. Helicopter is likely to exceed allowable gross weight with ENG equipment installed and four occupants.

**TAKEOFF PROCEDURE**

Stow laptop camera controller, video titler keyboard, and handheld microwave keypad during taxi and takeoff.

**APPROACH AND LANDING**

Stow laptop controller, video titler keyboard, and handheld microwave keypad, and retract omni antenna.

**SECTION 5: PERFORMANCE**      No change.

## **SECTION 6: WEIGHT AND BALANCE**

### **CAUTION**

Removal of nose-mounted camera causes a large shift in CG of empty helicopter. Calculate weight and balance prior to flight with camera removed to assure aft CG limit is not exceeded.

## **SECTION 7: SYSTEMS DESCRIPTION**

### **ELECTRICAL SYSTEM**

A 28-volt electrical system replaces the standard 14-volt system. The battery has been relocated to a battery box beneath the tailcone to balance the weight of the nose-mounted camera.

An additional circuit breaker panel on the ledge just forward of the pilot's seat contains all circuit breakers for ENG equipment. The forward row of circuit breakers is a 28-volt bus and the aft row is a 14-volt bus. A 28- to 14-volt converter located in the compartment under the right rear seat powers the 14-volt bus. The news equipment master switch on the left side of the panel controls power to all ENG equipment.

### **NOSE-MOUNTED CAMERA SYSTEM**

The nose-mounted camera system consists of a gyro-stabilized, gimbal-mounted video camera in the chin, and a power junction box in the compartment beneath the right rear seat. A fairing between the camera ball and chin minimizes the aerodynamic effects of the camera. The camera is operated from the left rear seat via a laptop controller.


**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**NOSE-MOUNTED CAMERA SYSTEM (cont'd)**


When not in use, the laptop controller may be stowed in the left front seat or right rear footwell as shown below. To stow the controller in the left front seat, disconnect wire harness and secure using both the seatbelt and tie-down strap.

**CAUTION**

The laptop controller is heavy and can cause injury if not secured during a hard landing. Always secure controller during taxi, takeoff, and landing operations.



**LEFT FORWARD SEAT**



**RIGHT REAR SEAT**

## **SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

### **AUDIO AND INTERCOM SYSTEM**

The audio system consists of four audio control panels and an audio junction box. The audio junction box is located in the compartment beneath the left front seat. Power is supplied via a 5-amp circuit breaker in the left hand circuit breaker panel. Power to the audio system is not disconnected by the news equipment master switch.

The pilot's audio panel is located in the console. Push buttons are used to select a primary (transmit and monitor) audio component. Green LEDs indicate which audio component is currently selected as primary. Additional components may be monitored by selecting their toggle switches up. Sliders control volume level for each component being monitored.

Intercom control is at the far right of the audio panel. Toggle switch down isolates the pilot from the intercom system, toggle switch up selects normal keyed intercom mode, and button depressed is voice-activated mode.

On helicopters equipped with a trigger-style intercom/transmit switch, the first detent of the pilot's trigger switch is the intercom key. The second detent transmits on Com 1. The thumb button transmits on the panel-selected audio component.

A toggle switch to the right of the OAT gage may be used to bypass the audio system and connect the pilot directly to Com 1. This mode is automatically engaged in the event of an audio system power failure. (The transmit indicator on Com 1's display can be used to verify transmission.)

## **SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

### **AUDIO AND INTERCOM SYSTEM (cont'd)**

The left front seat audio panel operates in the same manner as the pilot's audio panel but is not connected to the bypass toggle switch. On helicopters equipped with trigger-style intercom/transmit switches, the first detent of the co-pilot's trigger switch is the intercom key, and the second detent transmits on the panel-selected audio component. A handheld transmit switch has been added for use when the left cyclic grip is removed.

The rear seat audio panel is connected to both rear seat headset jacks. There is no voice-activated intercom mode for the rear seats. The left and right rear seat intercom switches have been relocated to the outboard side of the seat box and the rear-center console, respectively. In addition, the laptop camera controller contains intercom and transmit switches for the camera operator.

The microwave audio panel controls which signals are sent to the microwave transmitter. Selecting the toggle switch up for a component sends its signal to the transmitter. Push buttons are not functional on this panel.

### **FORWARD MONITOR INSTALLATION**

The forward monitor installation consists of two small color LCD monitors mounted side by side on top of the instrument panel. The right monitor displays nose camera, micro-camera, or video tape recorder images as selected by the video switcher. The left monitor displays TV broadcasts as selected by the TV tuner.

## **SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

### **AFT MONITOR INSTALLATION**

The aft monitor installation consists of two color LCD monitors mounted to the cross tube between the front seatbacks. Position and angle of the monitors is adjustable via friction swivel mounts.

The small, lower monitor displays TV broadcasts as selected by the TV tuner. The large, upper monitor may be switched between two modes. In Mode A, the monitor displays nose camera, micro camera, or video tape recorder images as selected by the video switcher. In Mode B, the video switcher is bypassed and the monitor displays nose-camera images directly.

### **VIDEO SWITCHER**

The video switcher is located in the rear console and is used to select the video signal source (nose camera, video recorder playback, or micro cameras). The signal is then routed to the monitors, microwave transmitter, and video tape recorder.

### **TV TUNER**

The TV tuner is mounted to the keel panel in the right rear footwell and is used to select television broadcasts to be displayed on the monitors.

### **MICRO CAMERA SYSTEM**


The micro camera system consists of up to three small cameras which may be mounted at the tip of the horizontal stabilizer, on the windshield bow, and on the aft cabin wall; and their control units which are in the rear-center console. The horizontal stabilizer camera is enclosed in a weather-proof case and may be accessed by unscrewing the front half of the case.



**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**VIDEO TAPE RECORDER**

The video tape recorder is located in the compartment beneath the right rear seat and controlled by a remote control mounted on the rear console. It is secured using the elastic cord as shown below.



**VIDEO TITLER**

The video titler consists of the processor located in the compartment beneath the right rear seat and a laptop keyboard. The keyboard is used to add captions to the nose-mounted camera video signal. In addition, the processor is connected to the helicopter's GPS receiver, allowing GPS coordinates to be displayed. Selecting "AUX" on the video switcher adds the titler signal to the nose-mounted camera signal.

When not in use, stow keyboard in the pouch beneath the right rear seat as shown above.

**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**MICROWAVE SYSTEM**

Two microwave transmitting systems are available on the ENG version.

The omnidirectional microwave transmitting system consists of the microwave transmitter beneath the right rear seat and a retractable omnidirectional microwave antenna on the right skid tube. The transmitter is operated via a controller in the rear-center console. The antenna is stowed parallel to the skid tube and rotated down to the vertical position for transmitting. It is actuated by an electric motor with the control switch located on the rear-center console. Lights next to the switch indicate whether the antenna is extended or retracted. The antenna is designed to break away without damaging the helicopter if inadvertently left extended during landing. However, damage to the antenna or actuation mechanism may occur.

**CAUTION**

Do not to kick or step on antenna. Insure antenna is retracted before landing.

The directional microwave transmitting system uses the same transmitter and transmitter controller as the omnidirectional system. The retractable antenna is replaced by a directional antenna in a pod under the belly. The directional antenna pod contains a GPS tracking system which keeps the antenna aimed at a ground-based receive site. The antenna controller is located in the compartment beneath the right rear seat.

Either transmitting system may be combined with an optional microwave receiver which is located beneath the right rear seat. Controls are located on the receiver face.

## **SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

### **FM TRANSCEIVERS**

FM transceiver #1 is mounted forward and below the left circuit breaker panel, and FM transceiver #2 is mounted in the rear-center console. Either transceiver is selectable from any of the three main audio control panels.

### **AM/FM RECEIVERS**

AM/FM receiver #1 is mounted adjacent to FM transceiver #1, and AM/FM receiver #2 is mounted adjacent to the TV tuner. Either receiver is selectable from any of the three main audio control panels.

### **INTERIOR LIGHT**

An additional interior light installed to the right of the rear headset hangers illuminates the rear center console and the camera operator's laptop controller. Power is supplied to the interior light via the "GAGES" circuit breaker in the left hand circuit breaker panel and is not disconnected by the news equipment master switch. The light is controlled by a switch on its face plate.

### **TALENT LIGHT**

The forward talent light is mounted on the left side of the instrument console and is used to illuminate the reporter during broadcasts in low-light conditions. Beam elevation is adjustable via a friction mount. The aft talent light is mounted at the top of the right door post and is used to illuminate the camera operator. Both lights are controlled by toggle switches on the rear-center console.

### ***CAUTION***

Talent lights may cause glare for pilot at night. Switch lights off if glare is objectionable.

## **SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

### **SIDE STROBE LIGHTS**

The side strobe light installation adds one strobe to each side of the fuselage adjacent to the position lights. The side strobes are controlled by a switch on the console. The tailcone-mounted strobe is powered any time the master battery switch is on. The single strobe circuit breaker provides circuit protection for all three lights.

#### **CAUTION**

Turn strobes off any time glare is objectionable. Glare may be objectionable at night when hover taxiing or operating with front doors removed.

### **SEATS, BELTS, AND BAGGAGE**

Baggage is not permitted under the left front and right rear seats due to electronic equipment and wiring in those compartments. A removable hinge pin allows the right rear seat bottom to be removed.

## **SECTION 8: HANDLING AND MAINTENANCE**

### **BATTERY SERVICE**

The battery is located in a battery box beneath the tailcone. It is sealed and does not require fluid level checks.

### **JUMP STARTING ENGINE**

Jump starting is not recommended due to limited access to battery and relay, and is not possible from a normal auto battery due to the 28-volt electrical system.


For battery charging, access to battery relay terminal A1 (labeled +24V) and a grounded tab (labeled -) is provided inside the aft cowl door.

FAA APPROVED  
R44 PILOT'S OPERATING HANDBOOK

SUPPLEMENT 9  
GARMIN GPSMAP 225

This supplement must be included in the FAA Approved Robinson R44 Pilot's Operating Handbook when the helicopter is equipped with the optional Garmin GPSMAP 225.

The information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic R44 Pilot's Operating Handbook.

APPROVED BY:   
*Acting* Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: 3/31/99

LOG OF PAGES

Page No.	Date
9-9.1	31 Mar 99
9-9.2	31 Mar 99

**SECTION 1: GENERAL**

Refer to Owner's Manual for use of the Garmin GPSMAP 225.

**SECTIONS 2 and 3** No change.

**SECTION 4: NORMAL PROCEDURES**

**DAILY OR PREFLIGHT CHECKS**

***CAUTION***

Dimmer may not dim display sufficiently for night flight. To further reduce brightness, increase contrast setting using Auxiliary menu and System Setup submenu. (Refer to Owner's Manual.)

**SECTIONS 5 thru 8** No change.

FAA APPROVED  
R44 PILOT'S OPERATING HANDBOOK

POP-OUT FLOATS SUPPLEMENT

This supplement must be included in the FAA-approved Pilot's Operating Handbook when pop-out floats are installed.

Information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic Pilot's Operating Handbook.


APPROVED BY:   
Manager, Flight Test Branch ANM-160L  
Federal Aviation Administration  
Los Angeles Aircraft Certification Office,  
Transport Airplane Directorate

DATE: 6-10-99

LOG OF REVISIONS

Page No.	Date	Page No.	Date
9-10.1	18 Dec 2015	9-10.8	18 Dec 2015
9-10.2*	18 Dec 2015	9-10.9	18 Dec 2015
9-10.3	18 Dec 2015	9-10.10	18 Dec 2015
9-10.4	18 Dec 2015	9-10.11*	18 Dec 2015
9-10.5	18 Dec 2015	9-10.12*	18 Dec 2015
9-10.6	18 Dec 2015	9-10.13*	18 Dec 2015
9-10.7	18 Dec 2015	9-10.14*	18 Dec 2015

\* Manufacturer's data, not FAA approved.

REVISIONS  
APPROVED BY:   
Manager, Flight Test Branch ANM-160L  
Federal Aviation Administration  
Los Angeles Aircraft Certification Office,  
Transport Airplane Directorate

DATE: December 18, 2015

**SECTION 1: GENERAL**

**INTRODUCTION**

This supplement contains the changes and additional data applicable when pop-out floats are installed.

Pop-out floats are intended for safety during over-water flights. Intentional water landings for other than training purposes are not recommended.

***NOTE***

The pop-out floats are not certified for ditching. Some countries may prohibit certain over-water operations.



## SECTION 2: LIMITATIONS

### AIRSPEED LIMITS

#### ADDITIONAL AIRSPEED LIMITS

100 KIAS maximum at power above MCP.

With floats stowed, 100 KIAS maximum with any combination of cabin doors removed.

80 KIAS maximum for float inflation.

80 KIAS maximum with floats inflated.

115 KIAS maximum with float system armed (safety catch in READY position).

### FLIGHT AND MANEUVER LIMITATIONS

Maximum altitude decrease with floats inflated is 4000 feet.

#### ***CAUTION***

Altitude loss greater than 4000 feet may cause floats to lose shape and rigidity due to atmospheric pressure increase. Do not inflate floats above 4000 feet AGL.

### PLACARDS

Near inflation lever:

$V_{ne}$  WITH FLOATS INFLATED: 80 KIAS

### SECTION 3: EMERGENCY PROCEDURES

#### POWER FAILURE – GENERAL

##### **CAUTION**

Lowering collective rapidly or applying excessive forward cyclic while helicopter is moving forward on water can cause floats to submerge and helicopter to nose over.

##### **CAUTION**

Float inflation may take up to three seconds. Squeeze inflation lever early enough to allow full inflation before water contact.

#### POWER FAILURE ABOVE 500 FEET AGL

Autorotation to land: Same as in basic manual.

Autorotation to water:

1. Lower collective immediately to maintain rotor RPM.
2. Reduce airspeed to below 80 KIAS.
3. Adjust collective to keep RPM between 97 and 108% or apply full down collective if light weight prevents attaining above 97%.
4. If altitude permits, maneuver into wind.
5. Inflate floats.

##### **CAUTION**

Do not inflate floats above 80 KIAS. Do not exceed 80 KIAS with floats inflated.

6. At about 40 feet AGL, begin cyclic flare.
7. At about 8 feet AGL, apply forward cyclic and raise collective just before touchdown. Touch down in slight nose high attitude with nose straight ahead.
8. Maintain cyclic in touchdown position and do not lower collective full down until forward motion has stopped.

**SECTION 3: EMERGENCY PROCEDURES (cont'd)**

**POWER FAILURE BETWEEN 8 FEET AND 500 FEET AGL**

Autorotation to land: Same as in basic manual.

Autorotation to water:

1. Lower collective immediately to maintain rotor RPM.
2. Reduce airspeed to below 80 KIAS.
3. Adjust collective to keep RPM between 97 and 108% or apply full down collective if light weight prevents attaining above 97%.
4. If altitude permits, maneuver into wind.
5. Inflate floats.

***CAUTION***

Do not inflate floats above 80 KIAS.  
Do not exceed 80 KIAS with floats inflated.

6. Maintain airspeed until water is approached, then begin cyclic flare.
7. At about 8 feet AGL, apply forward cyclic and raise collective just before touchdown. Touch down in slight nose high attitude with nose straight ahead.
8. Maintain cyclic in touchdown position and do not lower collective full down until forward motion has stopped.

**SECTION 3: EMERGENCY PROCEDURES (cont'd)**

**POWER FAILURE BELOW 8 FEET AGL**

Over land: Same as in basic manual.

Over water:

1. Apply right pedal as required to prevent yawing.
2. Inflate floats.
3. Allow rotorcraft to settle.
4. Raise collective just before touchdown.

**MAXIMUM GLIDE DISTANCE CONFIGURATION**

Same as in basic manual except airspeed 80 KIAS with floats inflated.

**EMERGENCY WATER LANDING – POWER OFF**

See procedures for power failures in this supplement.

**EMERGENCY WATER LANDING – POWER ON**

1. Reduce airspeed to below 80 KIAS.
2. Inflate floats.

***CAUTION***

Do not inflate floats above 80 KIAS.  
Do not exceed 80 KIAS with floats inflated.

3. Make normal approach and landing to water.

**SECTION 4: NORMAL PROCEDURES**

**DAILY OR PREFLIGHT CHECKS**

15. Pop-Out Floats

Float and float cover condition . . . . . Check  
Hose and fitting condition . . . . . Check  
Pressure cylinder . . . . . Check pressure  
Safety pin at pressure cylinder . . . . . Verify removed  
Inflation lever safety . . . . . "Ready" or "Locked"  
as required

***CAUTION***

Avoid night flight over water beyond autorotation distance to land. Height above water may be difficult to judge during a water landing.

***NOTE***

When OAT is below -10°C, there may be insufficient charge in pressure cylinder for full inflation.

**FLOAT INFLATION**

The red inflation lever located under the pilot's collective is equipped with a safety catch to prevent inadvertent float inflation. Prior to overwater flight, place the safety catch in the READY position. With the safety catch in the READY position, floats may be inflated by squeezing inflation lever.

Over land, safety catch should be reset to LOCKED position.

***CAUTION***

Observe 115 KIAS speed limitation when safety catch is in READY position.

**SECTION 4: NORMAL PROCEDURES (cont'd)**

**FLOAT INFLATION (cont'd)**

***CAUTION***

The pressure cylinder also has provisions for a safety pin at the valve on the cylinder neck. This safety pin is for use during maintenance and cylinder transport only and must be removed at all other times.

***NOTE***

Some flapping of float covers during flight with floats inflated is normal. To minimize wear, consider removing covers if an extended flight with inflated floats is required.

**SECTION 4: NORMAL PROCEDURES (cont'd)**

**OPERATION ON WATER**

Safe operation on water has been demonstrated in waves up to 1 foot (0.3 m) (trough to crest). Maximum recommended water taxi speed is 5 knots. Some application of collective is required.

Since the helicopter sits very low on water, it is likely that water will leak into the cabin. Intentional water landings should be limited to training. For training, seal the removable belly panels and landing gear cross tube cover using aluminum foil tape or duct tape. Avoid salt water if possible.

There may be limited tail rotor clearance to water, particularly at aft CG. Also, even small waves may cause enough rocking to dip the tail rotor in the water. If tail rotor contact with water is suspected, have tail rotor inspected prior to further flight. (If no noticeable change in vibration occurs after suspected water contact, helicopter may be repositioned to nearest convenient inspection site.)

***CAUTION***

If starting or stopping rotor on water, ensure area is clear as helicopter can rotate one or more complete turns while tail rotor RPM is low.

**SECTION 4: NORMAL PROCEDURES (cont'd)**

**PRACTICE AUTOROTATION – WITH GROUND CONTACT**

Same as in basic manual. Autorotations with floats stowed should only be performed to a smooth, hard surface to avoid damage to floats. Touch-down autorotations with floats inflated are not recommended due to the possibility of damage to floats.

**PRACTICE AUTOROTATION TO WATER**

Autorotation to water with floats inflated is same as practice autorotation with ground contact in basic manual except touch down in slight nose high attitude with nose straight ahead. Maintain cyclic in touchdown position and do not lower collective full down until forward motion has stopped.

***CAUTION***

Lowering collective rapidly or applying excessive forward cyclic while helicopter is moving forward on water can cause floats to submerge and helicopter to nose over.

***CAUTION***

There may be limited tail rotor clearance to water, particularly at aft CG. Applying excessive aft cyclic may cause tail rotor to contact water.

**SHUTDOWN PROCEDURE**

Add:

Inflation lever safety . . . . . LOCKED

**SECTION 5: PERFORMANCE**

No change.



## **SECTION 6: WEIGHT AND BALANCE**

### **WEIGHT AND BALANCE RECORD**

Basic empty weight and CG with pop-out float landing gear and pressure cylinder installed are included in the Weight and Balance Summary provided with the helicopter. If pressure cylinder is removed, update Weight and Balance Record. A charged pressure cylinder weighs 11.4 lb. The longitudinal arm of the cylinder is 41.2 inches from datum and the lateral arm is -8.5 inches from datum.



## **SECTION 7: SYSTEMS DESCRIPTION**

The pop-out float system consists of inflatable floats stowed in protective covers along the skid tubes, a pressure cylinder located in the compartment under the left front seat, flexible hoses from the cylinder to the floats, an inflation lever located on the pilot's collective, and an additional stabilizer installed at the base of the lower vertical stabilizer.

The pressure cylinder is of aluminum construction reinforced with carbon filament windings and is charged with helium. Proper pressure is indicated on a placard on the cylinder, and pressure can be checked using the gage on the cylinder valve.

A safety catch on the inflation lever can be set to prevent inadvertent actuation. With the safety catch in the READY position, floats are inflated by squeezing firmly on the inflation lever. (Approximately 20 lb force is required.) Float inflation time is approximately 2-3 seconds. With the safety catch in the LOCKED position, the inflation lever is locked out.

To operate the safety catch, push spring-loaded knob with thumb while rotating U-shaped pin with forefinger as shown in figure.



## **SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

The pop-out floats are approved for amphibious operation but are not certified for ditching. They are intended for enhanced safety during over-water flights. Intentional water landings for other than training purposes are not recommended.

### ***NOTE***

Floats maintain full pressure for at least 1 hour after inflation and typically maintain shape for several hours. Monitor float inflation state if helicopter is parked on water for an extended period.

## **SECTION 8: HANDLING AND MAINTENANCE**

### **GROUND HANDLING**

With floats installed, special ground handling wheels (Robinson part number MT980-1 and MT980-2) are required.

A safety pin is provided for installation at the pressure cylinder valve. This pin should be installed during maintenance and cylinder transport to prevent inadvertent pressure release.

### ***CAUTION***

With the safety pin installed, it is not possible to inflate the floats using the cockpit inflation lever. The safety pin is for use during maintenance and cylinder transport only and must be removed at all other times.

### **FLOAT TUBES AND COVERS**

Immediately replace any damaged float tube cover to minimize chance of float damage. Inspect float tube condition after each inflation. Refer to R44 Maintenance Manual for periodic inspection, float repacking, and cylinder recharge instructions.

INTENTIONALLY BLANK

**FAA APPROVED  
R44, R44 II, R44 CADET  
PILOT'S OPERATING HANDBOOK  
ADS-B EQUIPMENT SUPPLEMENT**

This supplement must be included in the FAA-approved Pilot's Operating Handbook when ADS-B equipment is installed.

The information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic Pilot's Operating Handbook.

APPROVED BY:   
*for* Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: June 27, 2016

**LOG OF PAGES**

Page No.	Date	Page No.	Date
9-12.1	27 JUN 16	9-12.4	27 JUN 16
9-12.2*	27 JUN 16	9-12.5	27 JUN 16
9-12.3*	27 JUN 16	9-12.6*	27 JUN 16

\*Manufacturer's data, not FAA approved.

## **SECTION 1: GENERAL**

### **INTRODUCTION**

This supplement contains the changes and additional data applicable when Automatic Dependent Surveillance-Broadcast (ADS-B) equipment is installed.

ADS-B is divided into two categories – ADS-B “Out” and ADS-B “In”.

ADS-B Out equipment transmits information to air traffic control to supplement radar/transponder information. The supplemental information allows optimization of flight plan routes and aircraft spacing.

ADS-B Out equipment may be required for operation in certain airspace. The R44 ADS-B Out installation has been shown to meet the requirements of 14 CFR § 91.227.

### ***NOTE***

The R44 ADS-B Out system operates on frequency 1090 MHz. This frequency is also accepted for ADS-B Out equipment in most countries outside the United States.

The ADS-B Out equipment consists of either a GPS receiver connected to the transponder or a transponder with built-in GPS. The transponder has ADS-B broadcast capability and broadcasts GPS position as well as additional preprogrammed information such as aircraft identification and type to air traffic control.

ADS-B In equipment receives traffic information from other ADS-B equipped aircraft. ADS-B In equipment may also receive additional traffic information and weather information from ground stations. The additional traffic and weather information from ground stations is only available in the United States

**SECTION 1: GENERAL (cont'd)**

**INTRODUCTION (cont'd)**

The ADS-B In equipment consists of a receiver (either installed under the left, front seat or built in to the transponder) and a suitable display. Refer to receiver and display manufactures' documentation for operation of ADS-B In equipment.

The R44 may be equipped with only ADS-B Out or with both ADS-B Out and ADS-B In.

**SECTION 2: LIMITATIONS**

**PLACARDS**

On transponder when ADS-B Out equipment is installed:

ADS-B OUT INSTALLED

**SECTION 3: EMERGENCY PROCEDURES**

No change.

**SECTION 4: NORMAL PROCEDURES**

**ADS-B SYSTEM OPERATION**

ADS-B system operation is mostly automatic and requires little pilot action. The GPS (if separate from the transponder), transponder, and ADS-B receiver (if installed) must all be powered and in normal operating modes for proper system function.

**ADS-B OUT**

The R44 ADS-B Out system is a single point of entry system. Mode 3/A codes, IDENT commands, and emergency codes are set on the transponder and are automatically incorporated in ADS-B Out broadcasts. The transponder should transition to ALT mode after takeoff for proper ADS-B Out broadcasts.

ADS-B Out broadcasts may be selected off by using menus associated with the transponder FUNC key.

***NOTE***

ADS-B Out may be required in certain airspace. Do not turn off ADS-B Out unless directed by air traffic control.

Malfunctions in the ADS-B Out system are annunciated by various messages on the transponder and/or GPS screen (refer to manufacturers' documentation).



**SECTION 4: NORMAL PROCEDURES (cont'd)**

**ADS-B SYSTEM OPERATION (cont'd)**

**ADS-B IN**

The ADS-B In receiver is either mounted underneath the left, front seat or is built in to the transponder. The receiver is powered by the Transponder/ADS-B circuit breaker.

ADS-B In data is sent from the receiver to a suitable display, often the primary GPS screen. The display may have dedicated traffic and weather views or may allow traffic and weather information to be overlaid on other data such as moving maps. Warnings such as traffic conflicts may also appear on the display. Refer to receiver and display manufacturers' documentation.

**SECTION 5: PERFORMANCE**

No change.

**SECTION 6: WEIGHT AND BALANCE**

No change.

**SECTION 7: SYSTEM DESCRIPTION**

**ADS-B SYSTEM**

The ADS-B Out system consists of either a GPS receiver connected to the transponder or a transponder with built-in GPS. The transponder broadcasts the aircraft's position, identification, and certain other parameters to air traffic control. ADS-B data is broadcast via the Extended Squitter (ES) feature of the transponder on a frequency of 1090 MHz. Note that change of aircraft registration may require update of pre-programmed parameters by qualified maintenance personnel.

Most of the data required for ADS-B broadcast such as aircraft type, ICAO address, and call sign are pre-programmed at installation. Flight-specific data such as Mode 3/A code and IDENT are entered using the transponder controls. The transponder uses these codes simultaneously for standard transponder as well as ADS-B broadcasts. There is no need to make a second code entry or to enter a code more than once. This is known as a "single point of entry" ADS-B system.

The ADS-B In system consists of a receiver (either mounted under the left, front seat or built in to the transponder) and a suitable display. The receiver receives both approved US ADS-B frequencies (978 MHz and 1090 MHz).

**SECTION 8: HANDLING, SERVICING AND MAINTENANCE**

No change.

FAA APPROVED  
R44 & R44 II PILOT'S OPERATING HANDBOOK  
AUTOPILOT SUPPLEMENT

This supplement must be included in the FAA-approved Pilot's Operating Handbook when the autopilot is installed.

The information contained herein supplements or supersedes the basic manual only in those areas listed in this supplement. For limitations, procedures, and performance information not contained in this supplement, consult the basic Pilot's Operating Handbook.


APPROVED BY:   
*for* Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: September 8, 2014

LOG OF REVISIONS

Page No.	Date	Page No.	Date
9-13.1	18 Dec 15	9-13.6*	18 Dec 15
9-13.2	18 Dec 15	9-13.7*	18 Dec 15
9-13.3	18 Dec 15	9-13.8*	18 Dec 15
9-13.4	18 Dec 15	9-13.9*	18 Dec 15
9-13.5*	18 Dec 15	9-13.10*	18 Dec 15

\* Manufacturer's data, not FAA approved.

REVISIONS  
APPROVED BY:   
Manager, Flight Test Branch, ANM-160L  
Federal Aviation Administration, LAACO  
Transport Airplane Directorate

DATE: December 18, 2015

## **SECTION 1: GENERAL**

### **INTRODUCTION**

This supplement contains the changes and additional data applicable when the autopilot is installed.

#### ***CAUTION***

The autopilot is intended to enhance safety by reducing pilot workload. It is not a substitute for adequate pilot skill nor does it relieve the pilot of the responsibility to maintain adequate outside visual reference.

The primary autopilot mode is Stability Augmentation System (SAS) mode which maintains a steady helicopter attitude by applying corrective inputs to the cyclic. The autopilot does not provide any collective or pedal inputs. Additional modes providing heading hold, altitude hold, and navigation functionality are also selectable.

## **SECTION 2: LIMITATIONS**

### **FLIGHT AND MANEUVER LIMITATIONS**

Minimum altitude for use of autopilot ALT mode is 200 feet AGL.

For practice instrument approaches, minimum altitude for use of autopilot VRT mode is 50 feet AGL.

Pilot's hand must be on cyclic grip under the following conditions:

During autopilot engagement or intentional disengagement

At airspeeds less than 50 KIAS when less than 500 feet AGL

### **SECTION 3: EMERGENCY PROCEDURES**

#### **AUTOPILOT DISENGAGEMENT OR FAILURE**

The autopilot is designed to automatically disengage if the system detects a fault. Disengagement is indicated by four beeps in the headset. If the autopilot does not automatically disengage, failure may be recognized by erratic cyclic control motion, abnormal cyclic stick forces, or deviations in pitch or roll.

1. Continue flight using manual control. If autopilot has not disengaged, manually disengage using cyclic AP OFF button or control panel SAS button.
2. If SAS annunciator on control panel is steady white, re-engagement may be attempted at pilot's discretion.

#### ***NOTE***

The system automatically switches off all modes except SAS mode at airspeeds below 44 KIAS or above 130 KIAS, accompanied by a single beep. This is by design and not a system failure.

### **SECTION 4: NORMAL PROCEDURES**

#### **GENERAL**

Autopilot controls and operating modes are described in Section 7, Systems Description.

#### ***NOTE***

Cyclic friction must be fully off for autopilot to work properly. Cyclic friction will degrade autopilot performance.

**SECTION 4: NORMAL PROCEDURES**

**STARTING ENGINE AND RUN-UP**

After "Hydraulic system", add:

Autopilot . . . . . Check

***NOTE***

For autopilot check, wear headset and ensure cyclic friction is off. Engage SAS mode, and verify cyclic exhibits centering tendency and SAS annunciator on control panel turns green. Disengage. Verify 4 beeps in headset, cyclic reverts to normal hydraulic system feel, and SAS annunciator turns white.

**TAKEOFF PROCEDURE**

Autopilot SAS mode may be engaged as desired on the ground or at any time during the takeoff procedure. Re-trim as necessary to eliminate undesirable cyclic forces.

**CRUISE**

Add:

Engage autopilot modes as desired. In SAS mode, re-trim as necessary to eliminate undesirable cyclic forces.

***CAUTION***

It is the pilot's responsibility to monitor flight controls, aircraft flightpath, traffic, and terrain even while the autopilot is engaged. Be prepared to take control if required.

**SECTION 5: PERFORMANCE**

No change.

**SECTION 6: WEIGHT AND BALANCE**

No change.

**SECTION 7: SYSTEMS DESCRIPTION**

**AUTOPILOT**

The autopilot system consists of two electric servomotors, a flight control computer, an autopilot control panel, and control buttons on the cyclic grip. One servomotor controls pitch and is installed in the control tunnel forward of the cyclic stick. The other servomotor controls roll and is installed under the pilot's seat. The servomotors are connected to the cyclic through electromagnetic clutches.

The flight control computer is installed on the forward panel under the pilot's seat, and the autopilot control panel is installed in the avionics stack.

In addition to the autopilot system components, an onboard attitude source such as an Attitude Heading Reference System (AHRS) is required.

The primary autopilot mode is Stability Augmentation System (SAS) mode which maintains a steady helicopter attitude by applying corrective inputs to the cyclic. This is felt as a light cyclic centering force. The autopilot senses aircraft attitude using a combination of sensors in the flight control computer and the onboard attitude source. The computer then sends signals to the servomotors which are connected to the bottom of the cyclic in the control tunnel. Additional modes may be layered on top of SAS mode and are described below.

## SECTION 7: SYSTEMS DESCRIPTION (cont'd)

### AUTOPILOT (cont'd)

Heading Mode (HDG) – maintains the heading selected by the heading bug on the directional gyro or Horizontal Situation Indicator (HSI) display. Aircraft can be steered using the heading bug.

#### **NOTE**

For large heading or course changes, the autopilot will use a maximum of 20° bank.

Altitude Mode (ALT) – maintains altitude at the time of engagement or of last TRIM button release. The target altitude is reset each time the TRIM button is pressed and released.

#### **NOTE**

The autopilot uses pitch attitude to maintain altitude or follow an approach glidepath. It does not have any control of power setting. The pilot must manage power with the collective to control speed and rate of climb or descent. Make small, smooth power changes to allow the system to adjust to new power settings.

Navigation Mode (NAV) – tracks the active GPS or VLOC course displayed on the Course Deviation Indicator (CDI). If no CDI is installed, NAV will only track the active GPS course displayed on the GPS.

NAV may be armed prior to intercepting the active course. NAV annunciator is white when NAV is armed and turns green at course intercept. If HDG is active when NAV is armed, the autopilot will fly the selected heading until course intercept. If HDG is not active, the autopilot will select a 45° intercept angle.



**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**AUTOPILOT (cont'd)**

Vertical Navigation Mode (VRT) – tracks an ILS glideslope or GPS approach vertical guidance. Arm VRT (annunciator turns white when armed) prior to intercepting the glidepath. VRT annunciator will turn green at glidepath intercept

***NOTE***

Pushing the ALT button while VRT is armed or active will turn off VRT. VRT must be re-armed or re-engaged as desired.

***NOTE***

Reducing power to approach setting just prior to glidepath intercept is recommended.

Backcourse Mode (BC) – reverse CDI sensing for backcourse approaches. Course on HSI should be set so that tail of course pointer points toward runway (set to inbound front course).

The control panel has a row of buttons to control autopilot modes and annunciators to indicate mode status. A dark annunciator indicates that a mode is off, a white annunciator indicates that a mode is armed or on standby, and a green annunciator indicates that a mode is active.

When the avionics master is switched on, the autopilot performs a self-test and then enters SAS standby mode. All of the control panel indicators flash alternating white and green during the self-test. Four headset beeps occur at the beginning of the self-test as a check of the aural warning function. The SAS annunciator on the control panel turns steady white when the self-test is complete.

***NOTE***

Autopilot will not enter standby mode if attitude indicator is not functioning or indicated bank angle is greater than 6 degrees.

## SECTION 7: SYSTEMS DESCRIPTION (cont'd)

### AUTOPILOT (cont'd)

The autopilot SAS mode is engaged either by pressing the SAS button on the control panel or by pressing the TRIM button on the cyclic for more than 1.25 seconds. Additional modes are engaged by pressing the appropriate button on the control panel. The additional modes are disabled and will not engage at airspeeds below 44 KIAS or above 130 KIAS.

To disengage any mode, push the appropriate button on the control panel.

#### ***NOTE***

Disengaging SAS mode will also disengage all other modes.

Modes may also be disengaged using the AP OFF button on the cyclic. If only SAS mode is engaged, push the AP OFF button once to disengage. If additional modes are engaged, push the AP OFF button once to disengage all modes except SAS and a second time to disengage SAS mode, or push and hold the AP OFF button to disengage all modes including SAS.

#### ***NOTE***

SAS disengagement is always accompanied by four beeps in the headset.

Safety monitors automatically disengage individual modes or the entire system if a fault is detected. Automatic disengagement of SAS mode (or the entire system) is indicated by four beeps in the headset. Automatic disengagement of any mode other than SAS is indicated by a single beep in the headset. There is no audio indication for intentional disengagement of modes other than SAS.

**SECTION 7: SYSTEMS DESCRIPTION (cont'd)**

**AUTOPILOT (cont'd)**

***NOTE***

The system also automatically reverts to SAS mode at airspeeds below 44 KIAS or above 130 KIAS, accompanied by a single beep.

The TRIM button is used to re-set the target attitude (to re-trim) while in SAS mode. Use a small amount of force to override the autopilot and then push and release the TRIM button at the new desired condition. If the force to override is objectionable, the TRIM button may be held down during maneuvers. The system will re-trim to the attitude at which the TRIM button is released.

***NOTE***

The system will not re-trim to more than 6° nose down, 11° nose up, or 10° of bank. If a re-trim is attempted outside these limits, the system will trim to the limiting value.

***NOTE***

When engaging SAS mode from standby, the autopilot uses the helicopter attitude at the time SAS mode is engaged as the target (trim) attitude. For large pitch and roll angles at the time of engagement, a target of 2° nose up pitch and 0° (level) roll is used.

The autopilot is protected by a dedicated circuit breaker on the avionics bus (autopilot is not powered with the avionics master switch off).

**REMOVABLE FLIGHT CONTROLS**

On later aircraft, disconnect the electrical connector for the left-hand trim button located near the quick release pin before removing the left cyclic grip. Reconnect the connector when installing the left cyclic grip.

## **SECTION 8: HANDLING AND MAINTENANCE**

No change.

## **SECTION 10: SAFETY TIPS**

The autopilot is intended to reduce pilot workload and enhance safety. It is important that pilots do not misuse this capability and allow their attention to be diverted from monitoring the helicopter attitude and looking for traffic and other obstacles. Autopilot disengagement requires immediate pilot attention. Pilots must always be prepared to take manual control.

The autopilot is not certified for flight in Instrument Meteorological Conditions (IMC). Adhering to appropriate VFR weather minimums is essential for safety.

If an inadvertent loss of outside visual reference occurs, the pilot must regain visual conditions as quickly as possible while avoiding abrupt, disorienting maneuvers. The following procedure is recommended:

1. If not already engaged, immediately engage autopilot SAS mode and allow autopilot to recover from unusual attitude if one has occurred.
2. Select a heading and altitude to ensure terrain and obstacle clearance. Turns and/or climbs may be required. Engage additional autopilot modes as desired for workload reduction.
3. While maintaining terrain and obstacle clearance, maneuver toward conditions of improved visibility.